

SAVE 95% OF YOUR PRINTING COSTS!

for ink-jet printers
CANON



DIRECTIONS

for filling / refilling the refillable cartridges

There are two access ports in the upper part of the cartridge: AIR (closed with a protective tape) and FILLING (closed with a rubber seal), the lower part of the cartridge is closed with an orange cover (Fig. 1).

Remove the rubber seal from the filling access port and remove the protective tape. Slowly pour the ink with an injector in the cartridge through the filling port (app. 10 ml) then close it with the rubber seal (Fig. 2).

Gently remove the orange cover from the cartridge (Fig. 3), and then install the cartridge in the printer (Fig. 4). ATTENTION, do not dispose of the orange cover; it can be useful for cartridges refilling or transporting.

When the message to change the cartridge appears (Fig. 5), press the STOP/RESET button on the printer and hold it for 10 or more seconds, - the ink level control will be disabled. In this case you should control the ink level by yourself and refill the cartridge on time.

www.inksystem.com
www.inksystem.biz
www.iccpro.com
www.kartridgam.net

inkSYSTEM®